




🎵 A music box will start playing by turning a knob.



☀️ Lights up the snow cave.



Provided in a beautiful acrylic case.



A handmade product over the details.

G Real size Frontage × Depth × Height	F Packing size Frontage × Depth × Height	G Weight
53×32×37(cm)	66×40×44(cm)	6kg