



hina143-242



♪ A music box will start playing by turning a knob.



☀ Lights up the snow cave.



Provided in a beautiful acrylic case.



A handmade product over the details.

G Real size Frontage × Depth × Height	F Packing size Frontage × Depth × Height	G Weight
48×29×33(cm)	56×37×40(cm)	5kg